Doubling:

If the 2 cards dealt to you total 11, you can double your bet and receive 1 card face down. When asked to double, touch 1 for yes and 0 for no.

Insurance:

If the dealers face up card is an ace, you can take out an insurance bet. When asked for insuranca touch 1 for yes and 0 for no.

To start a new hand:

Aftar a hand is complate and all bats have been settled, touch the enter key to start a new hand.

House rules:

- 1. Daaler declaras if ha has blackjack.
- 2. If a player has 21, he must stand.
- Hands where the dealer and a player have the same total is a push — nobody wins.
- Daaler stands on 17 or more and hits on 16 or less.

electronics, Inc. black jack operating instructions

BLACKJACK:

Game variations:

There are 3 game variations which set the amount of stake you start with and the betting limits.

- Game #1 Each player starts with \$100.00. Bets can be from \$1 to \$500 maximum.
- Game #2 Each player starts with \$1,000.00.

 Bets can be from \$1 to \$500 maximum.
- Game #3 -- Eech player starts with \$500.00.

 Bets can be from \$5 to \$25 maximum.

Number of players:

Either 1 or 2 people can play against the house. Player 1 always uses the left controllers, if there is a second player, he uses the right controller.

Number of decks:

You can select to play with 1, 2, 3 or 4 decks.

Shuffling:

Shuffling occurs at the beginning of eny game, or at the beginning of a hand if there ere 18 or less cards remaining. You can also request a shuffle when it is your turn to bet, by pulling your joystick controller forward (towards the keyboard).

The Playfield:

The playfield has a table in the center of the screen. The dealers cards will be shown on the table. The players cards will be shown to the left or right of the table (player 1 to the left). On the top of the screen of each of the players sides there are 3 lines with messages. The top line shows the amount of money left in that player's stake. The next line is used to show the bet on e hand. The bottom line gives various messages and questions.

Place your bets:

The players bet at the beginning of every hend. The pleyer whose turn it is to bet is indicated by a blinking square on his side of the screen. To enter a bet (when it's your turn), simply key in the number end press enter. You can clear the number with the clear key before pressing enter. Any illegal bets ere eutometically rejected.

The play:

After bets are placed, each player gets dealt 2 cards. Only the dealer has one of his cards face down. Each player is then asked to hit or stend. Press the 1 key to hit and 0 key to stand.